



RENEW USER MANUAL

GETTING STARTED

Using the power of ozone, the **OZRenew** is built to seek and destroy unwanted odors. Use in unoccupied spaces only.

- Connect the **OZRenew** to the power source.
- To turn on, press the button:
 - 1 time** - runs 30 minutes & 1 indicator lights up
 - 2 times** - runs 60 minutes & 2 indicators light up
 - 3 times** - runs 90 minutes & 3 indicators light up
 - 4 times** - runs 120 minutes & 4 indicators light up
- To activate Cycle Clean™ mode:
 - Hold button down for 3 seconds** - indicator lights oscillate and the unit runs 30 minutes on & 30 minutes off for a total of 12 hours
- To turn off, press button once and the lights will turn off.

CHANGING MODES

In order to change modes you must first turn the unit off by pushing the button once, then you can activate whichever mode you want.

WARNING

The unit has a cool down period of approximately 1 minute after being turned off.

USING THE OZRENEW WITH BOOT PUCKS

The **OZRenew** comes with a pair of boot pucks for you to deodorize your shoes. Connect one end of the transport tubing to the two ports on the bottom of the **OZRenew** unit and the other end to the port on both pucks. Insert a puck into each shoe and let the ozone destroy the odors.

WARNING

This product should only be used according to the instructions in this owner's manual. If used other than what has been specified here, serious injury may occur.

The ozone unit is designed to be used in unoccupied spaces only. Upon entering a room that was treated with ozone you should ventilate the area allowing any possible lingering ozone to be cleared out. Never aim ozone directly into your face; it may cause eye irritation or other side effects.

If entering a room where the unit was in use and the room is still filled with ozone (O₃ has not fully reverted back to O₂), it may cause mild headaches or irritation to the respiratory system. If this occurs, please exit the room immediately. If eyes continue to be irritated flush gently with water. If conditions continue seek medical attention. Keep away from children. Do not dismantle the ozone unit.

Depending on the concentration of bacteria and volume of odor, more than one cycle may be required to eradicate odors. Always allow for proper dissipation time between cycles. Exercise caution when using ozone on items with significant elastic or rubber content. Discontinue use on rubber or elastic items if you notice degradation or weakness to the structure of the items. Do not expose safety equipment to active odor destroyers. To prevent electric shock, do not plug or unplug unit with wet hands. Do not disassemble or insert items into unit. Doing so may cause damage or electric shock.

If you have any questions/concerns, please visit **OZbyScentLok.com** or call us at 800.315.5799

WARRANTY

We guarantee our product within one year of purchase. Please register at **OZbyScentLok.com/RegisterOZ**. The guarantee does not cover equipment which has been damaged due to abuse, misuse or accident, such as:

- use of incorrect line voltages;
- failure to follow the operating instructions provided by OZ;
- improper or unauthorized repair; or
- fire, flood, "acts of God," or other contingencies beyond the control of OZ.

Model: OZRenew
(4151390)

Power: 9W
Input Vol: AC 110v/60Hz

1731 Wierengo Dr., Muskegon, MI 49442
OZbyScentLok.com
©2019 Nexus Outdoors | 040319




GEAR CHAMBER

STEP 1: Take the product out of the carry bag.



- A. Carry Bag
- B. Gear Chamber Frame
- C. Hard corner pieces (8)
- D. Aluminum Tube - Long (4)
- E. Aluminum Tube - Medium (4)
- F. Aluminum Tube - Short (4)



STEP 2: Unfold the long (D) and medium (E) aluminum tubes.

STEP 3: Insert all four long tubes into the frame's vertical fabric piping.



Note:

Please read the instructions and retain for future reference. Care must be taken when opening, assembling, and disassembling the Gear Chamber to ensure that you do not trap or pinch your fingers. Always ensure that the item is fully assembled according to these instructions before use. Always check connectors are fully tightened before use. Always use on a firm, level surface.

STEP 4: Attach the long end of the four hard corner pieces (C) to the top of the long aluminum tubes.



STEP 5: Insert the two medium (E) and two short (F) tubes into the frame's top fabric piping, and then connect each end to the hard corner pieces.



STEP 6: Insert the two remaining medium (E) and two short (F) tubes into the frame's bottom fabric piping, and then connect each end to the hard corner pieces.



STEP 7: Attach velcro around the bottom bar to secure the base. Put the Gear Chamber on the ground.



STEP 8: Connect tubing from the OZRenew to the ports on the back of the Gear Chamber and begin use.

(Note: When removing tubing, hold the circular plate on the Gear Chamber in place to avoid ripping or tearing it away from the fabric.)



STORING THE GEAR CHAMBER:

Remove frame tubes and collapse the chamber onto its side, then fold in half so side pockets are facing out (B). Remove hard corners from piping then fold the long (D) and medium (E) pipes in half. Put all tubing & corners into the carry bag first, then put the Gear Chamber frame into the carry bag, zip closed.